1 , Customer need log in the APP with his account , also vvid 2 and vvdi keytool should be linked in that account what customer use to login

2 , Enter the account to share the authorization of ID48 copy from vvdi 2 to vvdi keytool , as below

Remark : One vvdi 2 only can share with one vvdi keytool , and both device need to linked in same account