

BMW 2011 03 01

| MENU | SYSTEM | ECU INFORMATION | READ DTC | CLEAR DTC | READ DATA STREAM | ACTION | SPECIAL FUNCTION |
|---------------------------------------|--------------------------------------|-----------------|----------|-----------|------------------|--------|---|
| R1200GS HP2 MegaMoto (2007+) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Idle Actuator Calibration, Engine Synchronization |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| | Central Vehicle Electronics | ✓ | ✓ | ✓ | | ✓ | Set the value of ddaption to zero |
| | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |
| R1200GS HP2 Enduro (2006- 2008) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Idle Actuator Calibration, Engine Synchronization |
| | Central Vehicle Electronics | ✓ | ✓ | ✓ | | ✓ | Set the value of ddaption to zero |
| | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |
| R1200GS Adventure (2006+) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Adaptation, Idle Actuator Calibration, Engine Synchronization |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| | Central Vehicle Electronics | ✓ | ✓ | ✓ | | ✓ | Set the value of ddaption to zero |
| | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |
| | Tyre Pressure Monitor (if fitted) | ✓ | ✓ | ✓ | | | |
| | Anti-Theft Alarm (if fitted) | ✓ | ✓ | ✓ | | | |
| | Special functions | | | | | | Set motorcycle date, Service reminder |
| R1200GS (2004+) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Adaptation, Idle Actuator Calibration, Engine Synchronization |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| | Central Vehicle Electronics | ✓ | ✓ | ✓ | | ✓ | Set the value of ddaption to zero |
| | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |

| | | | | | | | |
|-----------------|-----------------------------------|---|---|---|---|---|---|
| (2004+) | Tyre Pressure Monitor (if fitted) | ✓ | ✓ | ✓ | | | |
| | Anti-Theft Alarm (if fitted) | ✓ | ✓ | ✓ | | | |
| | Special functions | | | | | | Set motorcycle date, Service reminder |
| R1200R (2006+) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Adaptation, Idle Actuator Calibration, Engine Synchronization |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| | Central Vehicle Electronics | ✓ | ✓ | ✓ | | ✓ | Set the value of ddaption to zero |
| | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |
| | Tyre Pressure Monitor (if fitted) | ✓ | ✓ | ✓ | | | |
| | Anti-Theft Alarm (if fitted) | ✓ | ✓ | ✓ | | | |
| | Special functions | | | | | | Set motorcycle date, Service reminder |
| R1200RT (2005+) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Adaptation, Idle Actuator Calibration, Engine Synchronization |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| | Central Vehicle Electronics | ✓ | ✓ | ✓ | | ✓ | Set the value of ddaption to zero |
| | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |
| | Tyre Pressure Monitor (if fitted) | ✓ | ✓ | ✓ | | | |
| | Anti-Theft Alarm (if fitted) | ✓ | ✓ | ✓ | | | |
| | Special functions | | | | | | Set motorcycle date, Service reminder |
| R1200S HP2 | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Idle Actuator Calibration, Engine Synchronization |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |

| | | | | | | | |
|------------------------|--------------------------------------|---|---|---|---|---|---|
| (2007+) | Central Vehicle Electronics | ✓ | ✓ | ✓ | | ✓ | Set the value of ddaption to zero |
| | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |
| R1200S (2006+) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Adaptation, Idle Actuator Calibration, Engine Synchronization |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| | Central Vehicle Electronics | ✓ | ✓ | ✓ | | ✓ | Set the value of ddaption to zero |
| | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |
| | Tyre Pressure Monitor (if fitted) | ✓ | ✓ | ✓ | | | |
| | Anti-Theft Alarm (if fitted) | ✓ | ✓ | ✓ | | | |
| | Special functions | | | | | | Set motorcycle date, Service reminder |
| R1200ST (2005+) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Adaptation, Idle Actuator Calibration, Engine Synchronization |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| | Central Vehicle Electronics | ✓ | ✓ | ✓ | | ✓ | Set the value of ddaption to zero |
| | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |
| | Tyre Pressure Monitor (if fitted) | ✓ | ✓ | ✓ | | | |
| | Anti-Theft Alarm (if fitted) | ✓ | ✓ | ✓ | | | |
| | Special functions | | | | | | Set motorcycle date, Service reminder |
| R1200C (1998–2006) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Hall Sensor Signal Test, Hall Sensor Setting, TPS Adjustment |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| R1200CL (2002–2006) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Hall Sensor Signal Test, Hall Sensor Setting, TPS Adjustment |

| | | | | | | | | |
|-------------|---|--------------------------|---|---|---|---|---|--|
| K SERIES | (2002-2000) | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| | R1200GS Adventure 2 spark (2003- 2006) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Hall Sensor Signal Test, Hall Sensor Setting, TPS Adjustment |
| | | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| | R1150GS Adventure (2002-2003) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Hall Sensor Signal Test, Hall Sensor Setting, TPS Adjustment |
| | | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| | R1150GS 2 spark (2003- 2006) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Hall Sensor Signal Test, Hall Sensor Setting, TPS Adjustment |
| | | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| | R1150GS (2000- 2003) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Hall Sensor Signal Test, Hall Sensor Setting, TPS Adjustment |
| | | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| | R1150R 2 Spark (2003- 2006) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Hall Sensor Signal Test, Hall Sensor Setting, TPS Adjustment |
| | | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| | R1150R (2001-2003) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Hall Sensor Signal Test, Hall Sensor Setting, TPS Adjustment |
| | | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| | R1150RT 2 spark | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Hall Sensor Signal Test, Hall Sensor Setting, TPS Adjustment |

| | | | | | | | |
|-----------------------------------|--------------------------|---|---|---|---|---|--|
| spark (2003-2008) | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| R1150RT (2001-2003) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Hall Sensor Signal Test, Hall Sensor Setting, TPS Adjustment |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| R1150RS 2 spark (2003-2006) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Hall Sensor Signal Test, Hall Sensor Setting, TPS Adjustment |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| R1150RS (2001-2003) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Hall Sensor Signal Test, Hall Sensor Setting, TPS Adjustment |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| R1100GS (1993-1999) | Engine | | ✓ | ✓ | | | |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| R1100S 2 spark (2003-2006) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Hall Sensor Signal Test, Hall Sensor Setting, TPS Adjustment |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| R1100S (1998-2003) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Hall Sensor Signal Test, Hall Sensor Setting, TPS Adjustment |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| R1100R (1994-2001) | Engine | | ✓ | ✓ | | | |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| R1100RS (1993-2001) | Engine | | ✓ | ✓ | | | |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| R1100RT | Engine | | ✓ | ✓ | | | |

| | | | | | | | |
|-------------------|--------------------------|---|---|---|---|---|--|
| (1995-2001) | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| R850GS | Engine | | ✓ | ✓ | | | |
| (1999-2002) | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| R850R 2 spark | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Hall Sensor Signal Test, Hall Sensor Setting, TPS Adjustment |
| (2003-2008) | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| R850R | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Hall Sensor Signal Test, Hall Sensor Setting, TPS Adjustment |
| (2002-2003) | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| R850R | Engine | | ✓ | ✓ | | | |
| (1994-2003) | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| R850RT 2 spark | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Hall Sensor Signal Test, Hall Sensor Setting, TPS Adjustment |
| (2003-2008) | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| R850RT | Engine | | ✓ | ✓ | | | |
| (2001-2008) | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| R850RT | Engine | | ✓ | ✓ | | | |
| (1997-2002) | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| R859C | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Hall Sensor Signal Test, Hall Sensor Setting, TPS Adjustment |
| (1999-2004) | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |

| | | | | | | | |
|-------------------|--------------------------------------|---|---|---|---|---|--|
| F800GS (2007+) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Idle Actuator Calibration, Distance to Valve Check |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| | Central Vehicle Electronics | ✓ | ✓ | ✓ | | ✓ | Set the value of ddaption to zero |
| | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |
| | Anti-Theft Alarm (if fitted) | ✓ | ✓ | ✓ | | | |
| | Special functions | | | | | | Set motorcycle date, Service reminder |
| F800R (2007+) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Idle Actuator Calibration , Distance to Valve Check |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| | Central Vehicle Electronics | ✓ | ✓ | ✓ | | ✓ | Set the value of ddaption to zero |
| | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |
| | Tyre Pressure Monitor (if fitted) | ✓ | ✓ | ✓ | | | |
| | Anti-Theft Alarm (if fitted) | ✓ | ✓ | ✓ | | | |
| | Special functions | | | | | | Set motorcycle date, Service reminder |
| F800ST (2006+) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Idle Actuator Calibration , Distance to Valve Check |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| | Central Vehicle Electronics | ✓ | ✓ | ✓ | | ✓ | Set the value of ddaption to zero |
| | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |
| | Tyre Pressure Monitor (if fitted) | ✓ | ✓ | ✓ | | | |
| | Anti-Theft Alarm (if fitted) | ✓ | ✓ | ✓ | | | |
| | Special functions | | | | | | Set motorcycle date, Service reminder |
| | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Idle Actuator Calibration , Distance to Valve Check |

| | | | | | | | | |
|-------------|--|--------------------------------------|---|---|---|---|---|---|
| F SERIES | F800S (2006+) | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| | | Central Vehicle Electronics | ✓ | ✓ | ✓ | | ✓ | Set the value of adaptation to zero |
| | | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |
| | | Tyre Pressure Monitor (if fitted) | ✓ | ✓ | ✓ | | | |
| | | Anti-Theft Alarm (if fitted) | ✓ | ✓ | ✓ | | | |
| | | Special functions | | | | | | Set motorcycle date, Service reminder |
| | F650GS 800cc (2007+, 2cylinder 800cc) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | TPS adaptation,LAMBDA adaptation, Idle Speed Adaptation, Set value to zero |
| | | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| | | Central Vehicle Electronics | ✓ | ✓ | ✓ | | ✓ | Set the value of adaptation to zero |
| | | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |
| | | Tyre Pressure Monitor (if fitted) | ✓ | ✓ | ✓ | | | |
| | | Anti-Theft Alarm (if fitted) | ✓ | ✓ | ✓ | | | |
| | F650GS Darkar 2 spark (2004- 2008) | Special functions | | | | | | Set motorcycle date, Service reminder |
| | | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | TPS adaptation,LAMBDA adaptation, Idle Speed Adaptation, Set value to zero |
| | | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | | ABS Tests |

| | | | | | | | |
|--------------------------------------|-----------------------------|---|---|---|---|---|--|
| F650GS Darkar (2000-2004) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | TPS adaptation,LAMBDA adaptation, Idle Speed Adaptation, Set value to zero |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | | ABS Tests |
| F650GS 2 spark (2004- 2008) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | TPS adaptation,LAMBDA adaptation, Idle Speed Adaptation, Set value to zero |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | | ABS Tests |
| F650GS (2000-2004) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | TPS adaptation,LAMBDA adaptation, Idle Speed Adaptation, Set value to zero |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | | ABS Tests |
| F650CS 2 spark (2004-2006) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | TPS adaptation,LAMBDA adaptation, Idle Speed Adaptation, Set value to zero |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | | ABS Tests |
| F650CS (2002-2004) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | TPS adaptation,LAMBDA adaptation, Idle Speed Adaptation, Set value to zero |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | | ABS Tests |
| K1300GT | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Adaptation , Idle Actuator Calibration, Distance to Valve Check |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| | Central Vehicle Electronics | ✓ | ✓ | ✓ | | ✓ | Set the value of ddaption to zero |

| | | | | | | | |
|----------------|-----------------------------------|---|---|---|---|---|---|
| (2008+) | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |
| | Tyre Pressure Monitor (if fitted) | ✓ | ✓ | ✓ | | | |
| | Anti-Theft Alarm (if fitted) | ✓ | ✓ | ✓ | | | |
| | Special functions | | | | | | Set motorcycle date, Service reminder |
| K1300R (2008+) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Adaptation , Idle Actuator Calibration, Distance to Valve Check |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| | Central Vehicle Electronics | ✓ | ✓ | ✓ | | ✓ | Set the value of ddaption to zero |
| | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |
| | Tyre Pressure Monitor (if fitted) | ✓ | ✓ | ✓ | | | |
| | Anti-Theft Alarm (if fitted) | ✓ | ✓ | ✓ | | | |
| | Special functions | | | | | | Set motorcycle date, Service reminder |
| K1300S (2008+) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Adaptation , Idle Actuator Calibration, Distance to Valve Check |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| | Central Vehicle Electronics | ✓ | ✓ | ✓ | | ✓ | Set the value of ddaption to zero |
| | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |
| | Tyre Pressure Monitor (if fitted) | ✓ | ✓ | ✓ | | | |
| | Anti-Theft Alarm (if fitted) | ✓ | ✓ | ✓ | | | |
| | Special functions | | | | | | Set motorcycle date, Service reminder |
| | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Adaptation , Idle Actuator Calibration, Distance to Valve Check |

| | | | | | | | | |
|-------------|--------------------------------------|--------------------------------------|---|---|---|---|--|--|
| K SERIES | K1200GT (2006+) | Anti-Lock Braking System | √ | √ | √ | | √ | |
| | | Central Vehicle Electronics | √ | √ | √ | | √ | Set the value of ddaption to zero |
| | | Instrument Cluster | √ | √ | √ | | √ | |
| | | Tyre Pressure Monitor (if fitted) | √ | √ | √ | | | |
| | | Anti-Theft Alarm (if fitted) | √ | √ | √ | | | |
| | | Special functions | | | | | | Set motorcycle date, Service reminder |
| | K1200GT (non -CAN) (2003-2005) | Engine | √ | √ | √ | √ | √ | Hall Sensor Signal Test,Hall Sensor Setting 和 TPS Adjustment |
| | | Anti-Lock Braking System | √ | √ | √ | | | |
| | K1200LT (1999-2008) | Engine | √ | √ | √ | √ | √ | Hall Sensor Signal Test,Hall Sensor Setting 和 TPS Adjustment |
| | | Anti-Lock Braking System | √ | √ | √ | | | |
| | K1200R Sport (2006+) | Engine | √ | √ | √ | √ | √ | Adaptation , Idle Actuator Calibration,Distance to Valve Check |
| | | Anti-Lock Braking System | √ | √ | √ | | √ | |
| | | Central Vehicle Electronics | √ | √ | √ | | √ | Set the value of ddaption to zero |
| | | Instrument Cluster | √ | √ | √ | | √ | |
| | | Tyre Pressure Monitor (if fitted) | √ | √ | √ | | | |
| | | Anti-Theft Alarm (if fitted) | √ | √ | √ | | | |
| | | Special functions | | | | | | Set motorcycle date, Service reminder |
| | Engine | √ | √ | √ | √ | √ | Adaptation , Idle Actuator Calibration,Distance to Valve Check | |

| | | | | | | | |
|------------------------|--------------------------------------|---|---|---|---|---|--|
| K1200R (2005+) | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| | Central Vehicle Electronics | ✓ | ✓ | ✓ | | ✓ | Set the value of ddaption to zero |
| | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |
| | Tyre Pressure Monitor (if fitted) | ✓ | ✓ | ✓ | | | |
| | Anti-Theft Alarm (if fitted) | ✓ | ✓ | ✓ | | | |
| | Special functions | | | | | | Set motorcycle date, Service reminder |
| K1200RS (1997-2008) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Hall Sensor Signal Test, Hall Sensor Setting 和 TPS Adjustment |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | | |
| K1200S (2004+) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | Adaptation , Idle Actuator Calibration , Distance to Valve Check |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| | Central Vehicle Electronics | ✓ | ✓ | ✓ | | ✓ | Set the value of ddaption to zero |
| | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |
| | Tyre Pressure Monitor (if fitted) | ✓ | ✓ | ✓ | | | |
| | Anti-Theft Alarm (if fitted) | ✓ | ✓ | ✓ | | | |
| | Special functions | | | | | | Set motorcycle date, Service reminder |
| K1100LT (1994-1999) | Engine | | ✓ | ✓ | | | |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |
| K1100RS (1994-1994) | Engine | | ✓ | ✓ | | | |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | ✓ | |

G
SERIES

| | | | | | | | |
|-------------------------------|--------------------------|---|---|---|---|---|---|
| G650GS (2008+) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | TPS adaptation,LAMBDA adaptation, Idle Speed Adaptation, Set value to zero |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| G650 Xchallenge (2007+) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | TPS adaptation,LAMBDA adaptation, Idle Speed Adaptation, Set value to zero |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| G650 Xmoto (2007+) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | TPS adaptation,LAMBDA adaptation, Idle Speed Adaptation, Set value to zero |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| G650 Xcountry (2007+) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | TPS adaptation,LAMBDA adaptation, Idle Speed Adaptation, Set value to zero |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| G450X (2008+) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | TPS adaptation,LAMBDA adaptation, Idle Speed Adaptation, Set value to zero |
| C1-200 (2001-2006) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | TPS adaptation,LAMBDA adaptation, Idle Speed Adaptation, Set value to zero |
| | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | | ABS Tests |

C

| | | | | | | | | |
|-------------|-----------------------|--------------------------|---|---|---|---|---|---|
| SERIES | C1-125 (2000-2006) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | TPS adaptation,LAMBDA adaptation, Idle Speed Adaptation, Set value to zero |
| | | Anti-Lock Braking System | ✓ | ✓ | ✓ | ✓ | | |
| S SERIES | S1000RR (2010+) | Engine | ✓ | ✓ | ✓ | ✓ | ✓ | adaptation |
| | | Anti-Lock Braking System | ✓ | ✓ | ✓ | | ✓ | |
| | | Instrument Cluster | ✓ | ✓ | ✓ | | ✓ | |
| | | Special functions | | | | | | |