

The instruction of DATA SMART software update

The steps are similar among "active function", "software update" and "firmware update".




ECUTOOL[®]
www.ecutool.com


Take "software update " for example.

First please ensure you've installed USB driver well, connect the device to PC through USB and plug the test connector to the device. Then power on. Choose the option "PC_LINK", shown as

figures below



Run PC_LINK software on your PC, press "software update", you'll see the figures shown as below.



ECUTOOL[®]
www.ecutool.com

You'll see the process of updating for about 20 minutes, please wait with patience, don't do anything until you see "Updating software successfully", shown as figures below



After updating successfully, you could exit directly.